



## ASSEMBLY GUIDE

MODEL: DT1200



### ASSEMBLY INSTRUCTIONS


1. Unpack the unit, and place it on the ground. Pull the cord tight through the pole stand as in Figure 1.
2. Insert upper and lower tubes and press the spring bulge to ensure both tubes are securely placed, as in Figure 2.
3. Insert the connector piece into the stand base. Align pole and connect by screwing nut as in Figure 3.
4. Place the cable in the base as in Figure 4.
5. Your Dynatrap is now ready to be connected to the electrical outlet.

### INSTRUCCIONES PARA INSTALACION

1. Desempaque la unidad, y colóquela en el piso. Jale firmemente el cable através del tubo de la base, como se muestra en la Figura 1.
2. Inserte el tubo superior e inferior y apriete el botón con resorte para asegurarse que ambos tubos son colocados seguramente, como se muestra en la Figura 2.
3. Inserte el conector de plástico en la parte inferior de la base. Alinee el tubo y conecte por medio de la tuerca de plástico, como se muestra en la Figura 3.
4. Coloque el cable en la base, como se muestra en la Figura 4.
5. Su Dynatrap esta lista para ser conectada a la fuente de corriente.


### Figure 1

Pull the cord through the pole stand




### Figure 2

Insert both upper and lower tubes together and make sure the spring bulge is securely placed.



### Figure 3

Insert bottom connector piece into stand base.  
Align pole and connect by screwing nut.



### Figure 4

Place the unit in upright position

